

GUIDANCE





NOTE!

When parking the bed, the wheels must point away from the VENDLET actuator.





If the wheels of the bed are NOT pointed away from the actuator, the actuator can bump against the wheel when the bed is lowered to low altitude. If the actuator bumps against the wheel, it may break the actuator.

