



LIMB SLING – AT THE KNEE


If necessary the stiffener can be placed before use




The Limb sling is placed beneath the lower leg, where it is most appropriate for the care task to be done. However, it ought not to be placed too close to the ankle joint.




The Limb sling is pulled under the leg, taking care to keep a hand between the sling fabric and user's skin, and is placed centrally beneath the lower leg, so that even amounts of sling are on each side.




The Limb sling is now mounted to the lifting hanger.




If the Limb sling is used in connection with personal hygiene for bariatric patients, it can also be used as assistance to separate the thighs.




The Limb sling can also be utilized when fitting a lifting sling if the user has heavy or very heavy thighs or very compromised skin integrity.



The lower leg is lifted with the limb sling and the leg strap of the lifting sling is placed beneath the thigh.



The Limb lifter is lowered and removed.
The same process is done for the opposite leg.



LIMB SLING – AT THE WHEEL CHAIR

The Limb lifter is lead under the thigh at the back of the knee joint.



The Limb lifter is pulled through, taking care not to shear the user's skin, so that it is centralized in relation to the thigh lengthwise.



The Limb lifter is mounted to the lifting hanger and the thigh can now be lifted slightly from the seat. The sling's limb strap can now be placed either beneath the user's thigh or be drawn out without putting strain on the skin.

